


正面

Mode d'emploi du timer LB8869




Svp lisez attentivement avant utilisation




STRUCTURE PRODUIT

AVANT



ARRIERE



7 REGLAGES PREPROGRAMMES

Timer	1 min	3 min	5 min	15 min	30 min	60 min	90 min
-------	-------	-------	-------	--------	--------	--------	--------

FONCTIONS

- Durée max. de comptage : 89min, 59sec
- 7 réglages préprogrammés de compte à rebours : 1min / 3min / 5min / 15min / 30min / 60min / 90min
- Senseur gravitationnel Sensor Barrettes de progression
- Batterie rechargeable Type-C
- 3 niveaux de volume: fort / norm / mute x

BATTERIE

- Svp chargez le minuteur avant la première utilisation, l'écran restera sombre ou éteint si la puissance est trop faible.
- Câble Type-C, mais pas de fonction charge rapide.
- La lumière arrière est rouge durant la recharge, verte lorsque la recharge est terminée, svp débranchez alors l'appareil.

UTILISATION

- Allumez le timer par un bref appui .
- Placez la durée de comptage désirée face vers le haut, le timer démarre automatiquement.

COMPTAGE (COUNTUP)


- Placez face vers le haut, l'écran s'efface et indique 00:00.
- Bref appui pour démarrer le comptage (countup).
- Pendant le comptage, bref appui sur pour une pause ou reprendre le comptage, ou inclinez l'appareil pour remise à zéro.
- La durée de comptage maximum est de 89 min et 59 sec. A ce moment, l'appareil sonnera / flashera pendant 30 secondes et s'éteindra au bout de 60 secondes.

COMPTE A REBOURS (COUNTDOWN)


- Placez la durée désirée face vers le haut, le décompte démarre automatiquement avec un « bip ».

STRUCTURE DIAGRAM

FRONT



BACK



7 GROUPS FIXED COUNTDOWN TIME

Timer	1 min	3 min	5 min	15 min	30 min	60 min	90 min
-------	-------	-------	-------	--------	--------	--------	--------

FEATURES

- Max Countup time: 99min, 59sec
- 7 groups fixed countdown time : 1min / 3min / 5min / 15min / 30min / 60min / 90min
- With Gravity Sensor
- Red visual progress bar
- Battery: Rechargeable battery with Type-C charging port
- 3 levels volume: loud / normal / mute x

BATTERY

- Please charge this device first when using it for the first time, the screen will turn dark or can't power on when it with low power.
- Support Type-C cable, but the product not support fast charging.
- When charging, the light turn to red; When the light turn to green, it means the device with full power, please unplug the charging cable in time.

USE INSTRUCTION

- Turn on the device by short press .
- Place the fixed countdown time surface facing up, and the countdown will start automatically.


COUNTUP

- Put facing up, the screen will clear setting, and shows 00:00.
- Short press to start countup.
- During the countup timing, short press can pause or continue the timing.
- The max countup timing is 99min 59sec, When time reach to 99min 59sec, it will keep ringing / flashing for 30sec, then will turn off in 60sec.

COUNTDOWN


- Place the fixed countdown time surface facing up, start timing with a Di sound. The red bar will disappear one grid when the countdown time goes by one Tenth, when countdown timing ends and all progress bars disappear.
- Pause timing with the screen facing up, stop timing with the backside facing up or place surface facing up.
- Let the fixed timing surface facing up (already paused) can continue timing.
- When time is up, the device will keep ringing / flashing for 30sec, Put the device screen down can stop the count down and turn off the screen. Put the device screen up can pause the count down during the count down process.


For example: start 3 minute countdown



OTHER SETTING

- Short press to switch the 3 levels volume
loud → normal → mute x
- Power off:
 - Long press can turn off the timer.
 - Countup state 00:00 the screen will automatically turn off if without operation in 60sec.
 - Countdown pause state: the device will automatically power off in 30min (AVOID High power consumption), when countdown time is up, the device will keep ringing / flashing for 30sec, then turn off in 60sec. (this 60sec not included the front 30sec)






Little balance SAS- ZA Les Petites Ruelles, F-28130 Saint-Piat
www.littlebalance.net
Service Consommateurs : balancy@littlebalance.fr


背面

STRUCTURE DIAGRAM

FRONT



BACK



7 GROUPS FIXED COUNTDOWN TIME

Timer	1 min	3 min	5 min	15 min	30 min	60 min	90 min
-------	-------	-------	-------	--------	--------	--------	--------

FEATURES

- Max Countup time: 99min, 59sec
- 7 groups fixed countdown time : 1min / 3min / 5min / 15min / 30min / 60min / 90min
- With Gravity Sensor
- Red visual progress bar
- Battery: Rechargeable battery with Type-C charging port
- 3 levels volume: loud / normal / mute x

BATTERY

- Please charge this device first when using it for the first time, the screen will turn dark or can't power on when it with low power.
- Support Type-C cable, but the product not support fast charging.
- When charging, the light turn to red; When the light turn to green, it means the device with full power, please unplug the charging cable in time.

USE INSTRUCTION

- Turn on the device by short press .
- Place the fixed countdown time surface facing up, and the countdown will start automatically.


COUNTUP

- Put facing up, the screen will clear setting, and shows 00:00.
- Short press to start countup.
- During the countup timing, short press can pause or continue the timing.
- The max countup timing is 99min 59sec, When time reach to 99min 59sec, it will keep ringing / flashing for 30sec, then will turn off in 60sec.

COUNTDOWN


- Place the fixed countdown time surface facing up, start timing with a Di sound. The red bar will disappear one grid when the countdown time goes by one Tenth, when countdown timing ends and all progress bars disappear.
- Pause timing with the screen facing up, stop timing with the backside facing up or place surface facing up.
- Let the fixed timing surface facing up (already paused) can continue timing.
- When time is up, the device will keep ringing / flashing for 30sec, Put the device screen down can stop the count down and turn off the screen. Put the device screen up can pause the count down during the count down process.


For example: start 3 minute countdown



OTHER SETTING

- Short press to switch the 3 levels volume
loud → normal → mute x
- Power off:
 - Long press can turn off the timer.
 - Countup state 00:00 the screen will automatically turn off if without operation in 60sec.
 - Countdown pause state: the device will automatically power off in 30min (AVOID High power consumption), when countdown time is up, the device will keep ringing / flashing for 30sec, then turn off in 60sec. (this 60sec not included the front 30sec)





Little balance SAS- ZA Les Petites Ruelles, F-28130 Saint-Piat
www.littlebalance.net
Service Consommateurs : balancy@littlebalance.fr